


SHBN4 - BREAKDOWN



SHBN4 - PARTS LIST

KEY NO.	PART NUMBER	DESCRIPTION	KEY NO.	PART NUMBER	DESCRIPTION
1	NSP-154	Screw	31	NSP-163	Pin
2	NSP-182	Washer	32	NSP-093	Inner Trigger
3	NSP-074	Exhaust Deflector	33	NSP-095	Trigger
* 4	-----	Spring	34	NSP-096	Pin
* 5	-----	Seal	35	NSP-070	Shaft
6	NSP-077	Cylinder Cap Assy.	36	NSP-094	Spring
* 7	-----	Seal	37	NSP-097	Main Body Assy.
* 8	-----	Seal	38	NSP-069	Safety
9	NSP-079	Firing Valve Assy.	39	NSP-098	Guide Body
* 10	-----	Seal	40	NSP-099	Plate
* 11	-----	Seal	41	NSP-100	Door
12	NSP-082	Collar	42	NSP-103	Screw
+ 13	-----	Seal	43	NSP-135	Screw
+ 14	-----	Main Piston	44	NSP-105	Magazine Unit A
+ 15	-----	Driver (Regular)	45	NSP-104	Flat Bar
# 16	-----	Seal	46	NSP-106	Magazine Unit B
17	NSP-085	Cylinder Sleeve	47	NSP-107	Stopper
# 18	-----	Assy.	48	NSP-101	Stopper
✓ 19	-----	Piston Stop	49	NSP-184	Washer
20	NSP-088	Seal	50	NSP-108	Reel Plate
✓ 21	-----	Tube	51	NSP-109	Pusher
# 22	-----	Seal	52	NSP-110	Pusher
✓ 23	-----	Joint Guide	53	NSP-102	Spring
24	-----	Seal	54	NSP-111	Screw
25	NSP-072	-----	55	NSP-112	Bracket
✓ 26	NSP-124	Trigger Valve Assy.	56	NSP-113	Stopper
✓ 27	NSP-147	Seal	57	NSP-114	Stopper
28	NSP-071	Seal	58	NSP-115	Nut
✓ 29	NSP-092	Trigger Valve Guide	59	NSP-116	Screw
30	NSP-146	Spring Retainer	60	NSP-176	Air Plug

See next page for Repair Kit contents

