


LK580H2-1

LKC580V2



LK580H2-1

LKC580V2 (cont'd)

<u>Key No.</u>	<u>Part Number</u>	<u>Description</u>
1	SSV-3	Globe Valve
2	CAC-4337-1	Check Valve
3	•ABP-4900	Two-Stage Pump
4	BT-229	Belt
5	AC-0434	Outside Belt Guard
6	AC-0433	Inside Belt Guard
7	CAC-1004-1	Belt Guard Bracket
8	DAC-223	Outlet Tube
9	CAC-1365	Pressure Relief Tube
11	CAC-95	Manifold
12	DAC-278-2	Pressure Switch
13	SS-2072-1	Nipple (3/8 NPT)
14	SSP-434	Nipple (3/4 NPT)
15	SS-3222-CD	Pipe Plug (Not Shown)
18	MO-9044-1	Motor
19	SS-559	Set Screw
20	C-PU-2888	Pulley
21	SS-00403	Flywheel Direction Label
22	SS-2707	Drain Valve
24	SSF-3159	Pump Bolt
25	SSF-3140-ZN	Motor Bolt
26	SSF-8131	Speed Nut
27	SSF-8111-ZN	Lock Nut
28	SSF-953-ZN	Self Tapping Screw
29	91895680	Screw
31	SS-8553	Male Connector
36	TIA-4200	Safety Valve
37	SSP-7811	Nut Sleeve Assembly 1/4"
39	GA-347	Gauge
40	SSP-7812	Nut Sleeve Assembly 1/2"
41	DAC-225	Connector
42	CAC-1062	Isolator
43	*	Tank

NOT SHOWN

KK-4315	Pressure Relief Valve Kit
SUDL-65	Motor Shaft Key
SUDL-6-1	Rubber Foot Strip

***Non-serviceable part**

•See Pumps Tab