


V134 - AR - UNLOADER



V134 - AR - UNLOADER PARTS LIST

<u>Key#</u>	<u>Part#</u>	<u>Description</u>
1	AR-1080620	Knob, Unloader
2	AR-1080600	Spring
3	AR-1080630	Nut Ring
4	AR-1080360	Set Screw M3x4
5	AR-1080780	Spring Guide
6	AR-1080610	Seat
7	AR-1080540	Upper Piston
* 9	AR-1080640	Washer, Lock
* 10	AR-391000	O-Ring 09.13 x2 .62
11	AR-1560010	Unloader Body
12	AR-1540110	Washer Ring 3/8"G
* 13	AR-740290	O-Ring 014x1.78
* 14	AR-650540	O-Ring 04x2.5
15	AR-1540080	Set, Combination Bolt
19	AR-1560111	Nipple 3/8"
* 20	AR-180101	O-Ring 017.5x2
21	AR-1140070	Spring
22	15573	Valve
* 23	AR-1080550	O-Ring
* 24	AR-480480	O-Ring 04.48x1.78
25	AR-1080840	Lower Piston
27	AR-1560050	Adapter, Threaded
* 28	AR-390080	O-Ring 011.91x2.62
* 29	AR-770570	O-Ring 018.77x1.78
30	AR-154120	Washer Ring 1/2" Gas
32	AR-1540050	Inlet Fitting, Suction
36	AR-1540090	Bolt, Set
37	AR-2611	O-Ring Kit

*Available in O-Ring #AR-2611

General Information:

- Chemical injector used 15124

V134 - UNLOADER - AR - REPAIR KIT

AR-2611-Ring Kit

